

Broil King®

















Broil King
SOVEREIGN XL 20
9888-52
9888-53
9888-56




Broil King
SOVEREIGN XL 90
9888-82
9888-83
9888-86


HARDWARE INCLUDED / MATERIAL INCLUS / EQUIPOS INCLUIDO

Y-12865		X12	Y-11793		X8
S21420		X2	Y-11561		X4
Y-29304		X2	Y-11211		X6
S21124		X2	Y-12124		X2
Y-12673		X2	AAA		X1
S21061		X2	Y-29306		X2
Y-12310		X2	S21255		X2


TOOLS REQUIRED / OUTILS NECESSAIRES / HERRAMIENTAS NECESARIAS





1



(4)








(4)




2


(2)





3




4




5





6

(4) 




7


(2)




8




(1)






9


(2) 





10





11



(2) 

(2)










13






14

(1)




15


(1)




16




(1)




1







2









3





4





17










18





19









22





23




24




25



26



27



PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>9888-52</u>	<u>9888-53</u>	<u>9888-56</u>	<u>9888-82</u>	<u>9888-83</u>	<u>9888-86</u>
1	10909-E600	CASTING BOTTOM	1	1	1	1	1	1
2	10473-E600	CASTING TOP	1	1	1	1	1	1
3	10081-BK630	NAMEPLATE	1	1	1	1	1	1
4	10958-E600A	TOP CASTING INSERT	1	1	1	1	1	1
5	10571-6	HEAT INDICATOR	1	1	1	1	1	1
6	10240-15	HINGE PIN	2	2	2	2	2	2
6A	S21237	HINGE SPACER	2	2	2	2	2	2
7	S21233	HITCH PIN CLIP	2	2	2	2	2	2
9	10225-T536	GRID - S.S.	4	4	4	4	4	4
10	10222-E400	FLAV-R-WAVE	4	4	4	4	4	4
11	10225-E601	GRID - WARMING RACK	1	1	1	1	1	1
12	10222-E401	DIVIDER	3	3	3	3	3	3
13	10184-R86	BOSS EXTENSION	1	1	1	1	1	1
15	10390-E20D	BURNER	4	•	•	4	•	•
	10390-E20E	BURNER	•	4	•	•	4	•
	10390-E20NGE	BURNER	•	•	4	•	•	4
17	10342-245	ELECTRONIC IGNITOR	1	1	1	•	•	•
	10342-247	ELECTRONIC IGNITOR	•	•	•	1	1	1
18	10342-E13	ELECTRODE	2	2	2	2	2	2
19	10342-E600A	COLLECTOR BOX	1	1	1	1	1	1
21	10444-E70D	CONTROL ASSEMBLY	1	•	•	•	•	•
	10444-E70E	CONTROL ASSEMBLY	•	1	•	•	•	•
	10444-E71E	CONTROL ASSEMBLY	•	•	1	•	•	•
	10444-E76D	CONTROL ASSEMBLY	•	•	•	1	•	•
	10444-E76E	CONTROL ASSEMBLY	•	•	•	•	1	•
	10444-E77E	CONTROL ASSEMBLY	•	•	•	•	•	1
21A	S13470-073	HOSE-SIDE BURNER	1	•	•	1	•	•
	S13470-079	HOSE-SIDE BURNER	•	1	•	•	1	•
	S13470-109	HOSE-SIDE BURNER	•	•	1	•	•	1
21B	Y-11230	COTTER PIN	•	•	•	1	1	1
21C	10110-45	TUBE-REAR BURNER ASSY	•	•	•	1	1	1
23	22001-768	CONTROL KNOB	4	4	4	6	6	6
23A	10472-E38	CONTROL BEZEL	4	4	4	6	6	6
24	10111-16A	PIGTAIL HOSE ASSEMBLY	1	1	1	1	1	1
25	10222-E403	BAFFLE	2	2	2	2	2	2
26	10222-E404	BAFFLE	1	1	1	1	1	1
30	10194-E633	CONTROL COVER	1	1	1	•	•	•
	10194-E699	CONTROL COVER	•	•	•	1	1	1
31	10711-E42A	EDGE CAP	1	1	1	1	1	1
32	10711-E41A	EDGE CAP	1	1	1	1	1	1
33	10184-E85	RADIATION SHIELD	1	1	1	1	1	1
35	10184-E501	SUPPORT-CASTING-LEFT	1	1	1	1	1	1
36	10184-E511	SUPPORT-CASTING-RIGHT	1	1	1	1	1	1
37	10184-E651	SUPPORT-SIDE SHELF-LEFT	2	2	2	2	2	2
37A	10184-E63	SUPPORT-SIDE SHELF-LEFT	2	2	2	2	2	2
38	10184-E641	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2	2	2
38A	10184-E62	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2	2	2

PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>9888-52</u>	<u>9888-53</u>	<u>9888-56</u>	<u>9888-82</u>	<u>9888-83</u>	<u>9888-86</u>
39	10956-E661	BRACE-REAR	1	1	1	1	1	1
40	10711-E701	BASE	1	1	•	1	1	•
	10711-E711	BASE	•	•	1	•	•	1
40A	10184-D821	TANK BRACKET	1	1	•	1	1	•
41	10956-E691	BRACE-FRONT	1	1	1	1	1	1
42	10958-E89	DOOR	2	2	2	2	2	2
42A	10958-E951	DOOR – INNER	2	2	2	2	2	2
43	10958-E761	SIDE PANEL	2	2	2	2	2	2
44	10958-E921	PANEL - REAR	1	1	1	1	1	1
45	10184-E931	BRACKET - DOOR CATCH	1	1	1	1	1	1
48	10184-E681	BRACKET - SHELF	4	4	4	4	4	4
49	10711-E84	CONDIMENT BIN	2	2	2	2	2	2
50	10711-E92	SHELF - SIDE	1	1	1	1	1	1
51	10711-E93	SHELF-SIDEBURNER	•	•	•	1	1	1
	10711-E92	SHELF - SIDE	1	1	1	•	•	•
52	10184-E88A	DOOR - TOP CAP - LEFT	1	1	1	1	1	1
53	10184-E86	DOOR - BOTTOM CAP - LEFT	1	1	1	1	1	1
54	10184-E89A	DOOR - TOP CAP - RIGHT	1	1	1	1	1	1
55	10184-E87	DOOR - BOTTOM CAP - RIGHT	1	1	1	1	1	1
56	10892-8NG	WHEEL	2	2	2	2	2	2
58	10711-E721	CABINET SHELF	1	1	1	1	1	1
60	10711-E47	END CAP - SHELF	1	1	1	1	1	1
61	10711-E44	EDGE CAP - SHELF	1	1	1	1	1	1
62	10711-E45	EDGE CAP - SHELF	1	1	1	1	1	1
63	10711-E48	END CAP - SHELF	1	1	1	1	1	1
64	10711-E43	EDGE CAP - SHELF	1	1	1	1	1	1
65	10711-E46	EDGE CAP - SHELF	1	1	1	1	1	1
66	S13016A	BURNER ROTISSERIE	•	•	•	1	1	1
67	S15509	ELECTRODE	•	•	•	1	1	1
68	S21362	SPRING	•	•	•	1	1	1
70	Y-11990	HEX NUT	•	•	•	1	1	1
71	10696-105	REAR BURNER-ORIFICE	•	•	•	1	•	•
	10696-115	REAR BURNER-ORIFICE	•	•	•	•	1	•
	10696-170	REAR BURNER-ORIFICE	•	•	•	•	•	1
73	S21420	PUSH NUT	2	2	2	2	2	2
74	S21084	SCREW #14 x 3/4	10	10	10	10	10	10
75	10184-E713A	HANDLE	1	1	1	1	1	1
76	S21255	WASHER	4	4	4	4	4	4
78	10892-22	CASTOR	2	2	2	2	2	2
79	Y-11561	SCREW 1/4:20 x 1 3/4	8	8	8	8	8	8
80	Y-11546	SCREW 1/4-20 X 5/8	8	8	8	8	8	8
81	Y-12860	SCREW 1/4-20 X 1 3/8	8	8	8	8	8	8
82	Y-12673	SHELF - LOCK PIN	2	2	2	2	2	2
83	Y-12310	SCREW 1/4:20 x 3/4	2	2	2	2	2	2
84	S15170	AXLE	1	1	1	1	1	1
87	Y-11793	NUT 1/4-20	18	18	14	18	18	14
88	Y-12865	SCREW 1/4-20 X 1/2	16	16	14	16	16	14

PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>9888-52</u>	<u>9888-53</u>	<u>9888-56</u>	<u>9888-82</u>	<u>9888-83</u>	<u>9888-86</u>
89	Y-11211	WASHER	6	6	6	6	6	6
96	S21125	SCREW 8 X 3/8	16	16	16	16	16	16
98	S21124	SCREW 8 X 1/2	36	36	36	38	38	38
98A	Y-12643	SCREW 8 X 1/2	16	16	16	16	16	16
99	Y-12646	SCREW SHOULDER 8 X 1/2	•	•	•	2	2	2
104	Y-12835	SCREW 6-32 X 1/4	•	•	•	2	2	2
106	Y-12861	SCREW 1/4-20 X 3/8	•	•	•	2	2	2
107	Y-12863	WASHER	•	•	•	4	4	4
110	23009-99	GRID	•	•	•	1	1	1
111	10390-R81A	SIDE BURNER	•	•	•	1	1	1
113	10342-T18	ELECTRODE	•	•	•	1	1	1
114	23000-253	COVER-SIDE BURNER	•	•	•	1	1	1
117	23000-271	SHELF-SIDE BURNER	•	•	•	1	1	1
121	10184-E611	CASTOR SUPPORT	1	1	1	1	1	1
122	10184-E582	CASTOR SUPPORT	1	1	1	1	1	1
123	S15115	GREASE PAN - DISPOSABLE	2	2	2	2	2	2
124	Y-12117	BUSHING	•	•	•	2	2	2
125	Y-12220	BUSHING	•	•	•	1	1	1
135	Y-12119	BUSHING	2	2	2	3	3	3
136	10184-E43	ROTISSERIE SHIELD	1	1	1	1	1	1
137	10184-E42	ROTISSERIE BRACKET	1	1	1	1	1	1
138	10184-E44	ROTISSERIE SHIELD	1	1	1	1	1	1
139	Y-29306	WING NUT	2	2	2	2	2	2
140	S21061	SCREW 10-24 x 3/4	2	2	2	2	2	2
141	S15271	HANDLE	•	•	•	1	1	1
142	S15270	BALANCER	•	•	•	1	1	1
143	S15263	BUSHING	•	•	•	1	1	1
144	S15287	4 PRONG FORKS	•	•	•	4	4	4
145	S15258	SPIT ROD	•	•	•	1	1	1
146	S15246	ROTISSERIE MOTOR	•	•	•	1	1	1
147	S15299	WASHER	•	•	•	1	1	1
155	Y-12124	DOOR PIN CAP	•	•	•	2	2	2
157	Y-12871	SCREW M4 X 0.7	•	•	•	2	2	2

